

HANSON OFFROAD

12539 Jomani Drive Bakersfield, CA 93312
P:877.757.9779 sales@hansonoffroad.com

CB38-P SMALL BASKET INSTALLATION

This Hanson basket mounts to the top of the CTF38-P Tall Cargo Frame.

NOTE: 3M foam tape and aluminum pop rivets are included to mount the aluminum floor to the base of the basket. The foam tape reduces rattle and the rivets secure the floor for daily driving. Customer will need to drill the necessary holes to install rivets.

1. Place flat washers on the 4 bolts that are supplied to prepare for installation.
2. Place basket on top of cargo frame. Position basket so that it is flush with the back side of cargo frame support brackets.
3. Insert bolt in driver side rear hole on basket and through cargo frame bracket. Secure bolt with washer and nut. Do not tighten.
4. Insert bolt and washer into other hole on basket and through cargo frame bracket. Secure bolt with washer and nut. Do not tighten.
5. Insert bolt in passenger side rear hole on basket and through cargo frame bracket. Secure bolt with washer and nut. Do not tighten.
6. Insert bolt and washer into other hole on basket and through cargo frame bracket. ***It may be necessary to force cargo frame bracket left or right to line up bolt holes on the passenger side before inserting bolts.*** Secure bolt with washer and nut and tighten to 20 FT/LBS torque.
7. Return to other three bolts and tighten to 20 FT/LBS torque

