

# HANSON OFFROAD

12539 Jomani Drive Bakersfield, CA 93312  
P:877.757.9779 [sales@hansonoffroad.com](mailto:sales@hansonoffroad.com)

## JK FRONT BUMPER INSTALLATION INSTRUCTIONS

*These instructions cover the installation of the following part numbers: JKSL1102-P, JKSL1202-P, JKSL1302-P, JKSL1402-P, JKML1102-P, JKML1202-P, JKML1302-P, JKFL1302-P, JKFL1402-P*



Remove stock bumper and factory valence. Also remove stock fog lights from the bumper.



Lift Hanson bumper into place over the ends of the frame. Insert 1/2" bolt with washer from inside the bumper through the frame.



Install remaining 1/2" bolts (4 per side) and snug. Step back from the vehicle and align bumper to the Jeep. Tighten all hardware.



If installing a winch, the fairlead plate will mount on top of the bumper and below the winch.



With the factory fog light removed, drill out the two tabs on the light out to 5/16". Mount using the supplied bracket and the 1/4" bolt. Complete for both lights.



Install light and bracket inside of the bumper using the supplied 1/4" button head bolts. The bolt will install from the bottom up through the bumper and bracket.



Recheck and ensure all bolts are tight.

Recheck all hardware after 500 miles and after off-road trips