

HANSON OFFROAD

6951 McDivitt Drive Bakersfield, CA 93313
P:877.757.9779 sales@hansonoffroad.com

JXJ1102/1202/1402-P: JEEP CHEROKEE (XJ) FRONT WINCH BUMPER INSTALLATION (BASIC, WINCHGUARD, FENDERBAR)

1. All factory front bumper mount hardware will need to be retained for installation. With the stock front bumper removed, slide the bumper into place. Using the factory bolts, loosely mount the bumper to the vehicle.

With all bolts started on the mount brackets, align bumper to the vehicle (align to grill and fender). Tighten all hardware.

