

HANSON OFFROAD

12539 Jomani Drive Bakersfield, CA 93312
P:877.757.9779 sales@hansonoffroad.com

XJRP ROCKSLIDER INSTALLATION

Installation of these rockers is fairly straightforward. With the rocker skid positioned correctly in place, clamp to the tub/rocker of the Jeep as shown in the photo below. Once in place, transfer the mount holes and drill 5/16" holes. Complete installation using the supplied hardware.



1. Install lower mount rail to the body of the Cherokee as shown.



2. With the rail snugly in place. Install the rocker and align along the body.



3. With the rocker in place, transfer all holes along the body to be drilled.

Once the holes are transfer, remove the rocker and drill all holes. Using supplied rivet nuts and corresponding tool, install the nuts to the body.

4. Installation is opposite for the driver's side of the vehicle. The mount rail is used as the guide for proper fitment along the rocker of the Cherokee.

Questions, please call the tech department at 661.847.0188

